



Comfort Zone CZ6C Motor Replacement

This guide will teach the user how to properly replace the motor. The Comfort Zone CZ6C motor is located inside the motor housing and this guide will teach repair or replacement as needed.

Written By: Gage Wilson



INTRODUCTION




Before replacing your fan's motor, use this [Comfort Zone CZ6C Fan Blades Replacement Guide](#).




TOOLS:


- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Motor






 Make sure to unplug the Comfort Zone CZ6C before replacing the motor. This will prevent the risk of electrocution.

- Unscrew the main housing screw located right above the main switch using a phillips screw driver.
- Then use gentle force to remove the main housing door.

 Remember to keep track of your screws!

Step 2




- Unscrew the two adjacent housing screws to free the motor cage from the housing.

Step 3




- Remove the motor cage from the fan housing.

Step 4



- Unscrew the two adjacent motor cage screws to free the motor

Step 5



- The motor is now free to be replaced.

i If the motor will not move out of its now freed state you can use WD-40 to loosen it

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-01 01:17:08 AM.